

- ▶ Locating Leak Detection System
- ▶ 4 Independent Zones
- ▶ 4 Simultaneous Leaks can be Detected
- ▶ Touch Screen Display
- ▶ MODBUS/JBUS Integration
- ▶ Sensibility Adjustable

## Description

The FG-ALS4, Four Zones Alarm & Locating Unit is designed to be used with TTK analog sense cables: FG-ECS, FG-ACS and FG-ECX, FG-ACX to give instant detection of liquid leaks (water, acid or base).

In the event of liquid leak or fault on the sense cables in any zone, the FG-ALS4 will respond as follows:

- An audible alarm is triggered and a relay is activated.
- The touch screen of the panel displays the zone, the location of the leak (to the nearest 1 metre) and details of the fault (the type of fault leak or cable break).
- Event report is sent to the BMS via MODBUS /JBUS.

To mute the alarm sound, simply touch the screen, or the panel will mute the alarm sound automatically when the leak or break is cleared.

## Features & Benefits

### FEATURES

- Available in both wall mounted and rack mounted (19" and 3U).
- The FG-ALS4 unit can control up to 45 metres of sense cable per zone.
- 3.2" touch-screen gives a clear indication of the system status.
- 4 detection zones are available.
- 5 relays are available, 4 for leak and 1 for cable break (all zone)+power failure.
- RS485 serial link with MODBUS/JBUS communication protocol for interfacing with BMS is available.

### BENEFITS

- Accurate reporting of leak location to one metre.
- Detects cable break faults.
- The sensibility of the unit is adjustable via the potentiometer on the PCB.
- Compatible with existing monitoring systems.
- User-friendly system - users can customise the system with the sub menus accessible from the home screen, to set up the unit.
- The FG-ALS4 unit is accurate and easy to use, ideal for small and medium applications where accurate leak location is required.

## Technical Data


<b>Compatibility</b>	Analog sense cables: FG-ECS, FG-ECX, FG-ACS, FG-ACX
<b>Enclosure Type</b>	ABS flame retardant UL94V0
<b>Operating Temperature</b>	-5°C to 55°C
<b>Serial Interface Physical Support</b>	Optoisolated two wire RS485
<b>Serial Link Parameters</b>	9600 baud, 8 data bits, 1 stop, no parity
<b>Supported Protocol</b>	MODBUS, function 3
<b>Relays Type: Leak + Cable Break</b>	5 SPDT single contact NO-NC
<b>Relay Max. Switching Voltage</b>	125VAC and 220VDC
<b>Relay Max. Switching Capacity</b>	60W (30V x 2A)
<b>Supply Current (typ.)</b>	0.25A/115VAC 0.15A/230VAC
<b>Supply Voltage</b>	100-240 VAC, 50/60Hz
<b>Dimensions (W,H,D)</b>	Wall mounted: 168 x 153 x 56 mm; Rack mounted: 482.60 x 132.56 mm
<b>Ingress Protection (IP)</b>	IP40

# Screen Shots

- The first button (flag) allows to change the system language: English / French / German



- The third button (gears) allows to change the Modbus slave number and to set the «mute» mode:



- The second button (arrows) allows to show the installed lengths on each of the four zones:

ZONE 1 20 m	ZONE 2 5 m
ZONE 3 45 m	ZONE 4 15 m

- In the case of faults (leak or cablebreak), the touch screen shows below:  
The leak alarms, represented by a drop of liquid;  
The cablebreak alarms, represented by scissors and the "sensor" label.

ZONE 1 SENSOR	ZONE 2 
ZONE 3 16m	ZONE 4 SENSOR

## Electrical Specification

Power Supply	N : Neutral / L : Line /  : Earth
RS485	R1 : COM / R2 : RT+ / R3 : RT-
Cable Break Relay	R1 : NO / R2 : COM / R3 : NC
Leak Relay	R1 : NO / R2 : COM / R3 : NC
FG-CLC Leader Cable	A : Green wire / B : White wire / C : Black wire / D : Red wire

## Identification Codes

FG-ALS4 F	Four zones alarm & location system unit - wall mounted
FG-ALS4 E	Four zones alarm & location system unit - rack mounted (19", 3U)
FG-ECS, FG-ACS and FG-ECX, FG-ACX	Water or acids sense cable in 3m, 7m, and 15m in length
Accessories:	
FG-CLC	Leader cable of 3.5 metres length
FG-TMX	End termination plug
CF-EC100	100 hold-down clips with glue
ES-EC	40 tags

## Certificates



The FG-ALS4 unit meets the requirements of all European Standards in EN 50081 and EN 50082 EMC.  
FG-ALS4 meets the TÜV requirements, according to IEC 61010-1/A2.

All the connections in the FG-ALS4 alarm locating system unit must be done with the power supply switched off.  
Read carefully the installation procedure for the FG-ALS4 alarm locating system unit.

This brochure has been carefully prepared to ensure technical accuracy but is only intended for promotional use. TTK UK cannot guarantee that the information contained herein contains no errors or omissions, and hence does not accept responsibility related to the use of its equipment. TTK maintain its obligations set forth in the Standard Terms and Conditions of Sale and will not, under any circumstances, assume liability for any incidental damages, indirect or consequential, arising from the sale, resale, use or misuse of this project. The purchaser(s) accept their responsibility as the sole judge(s) of the adaptability of the product for the intended use.  
FG-SYS and TOPSurveillance are trademarks of TTK S.A.S. © TTK 2021